



### 1. Restore Factory Settings

Plug the transformer into the power outlet and hold the "OK" button for 5 seconds. The clock will display 88:88. After 1 second, the clock will automatically set to 12:00.

### 2. Set Local Time

Press the "P" button. The "P" indicator will light up white, and the "AM/PM" indicator will start flashing. Select AM or PM by pressing the "▲" or "▼" buttons and confirm with the "OK" button. The hour display will then start flashing. Set the correct hour by pressing the "▲" or "▼" buttons and confirm with the "OK" button. Next, the minutes will start flashing. Set the correct minutes by pressing the "▲" or "▼" buttons and confirm with the "OK" button. The local time is now set.

### 3. Select Modes per Zone

Press the "Zone 1" or "Zone 2" button to configure the lighting. Press the same button multiple times to cycle through the following modes:

- OFF – The lights remain off.
- ON – The lights remain on.
- DUSK/DAWN – Lights turn on at dusk and off at dawn.
- 2H, 3H, 4H, 6H, 8H – Lights turn on at dusk and turn off after 2, 3, 4, 6, or 8 hours.
- DUSK/TIMER – Lights turn on at dusk and off at the preset time.

To set the time for turning off the lights:

Press the "OK" button. The clock will display OFF. Press the "OK" button again. The clock will display 12:00 (on the first setup). The "AM/PM" indicator will start flashing. Select AM or PM by pressing the "▲" or "▼" buttons and confirm with the "OK" button. The hour display will then start flashing. Set the correct hour by pressing the "▲" or "▼" buttons and confirm with the "OK" button. Next, the minutes will start flashing. Set the correct minutes by pressing the "▲" or "▼" buttons and confirm with the "OK" button. The off-time is now set.

- TIMER – Lights turn on and off at preset times, regardless of ambient light conditions.

To set the on and off times for the lights:

Press the "OK" button. The clock will display ON. Press the "OK" button again. The clock will display 12:00 (on the first setup). The "AM/PM" indicator will start flashing. Select AM or PM by pressing the "▲" or "▼" buttons and confirm with the "OK" button. The hour display will then start flashing. Set the correct hour by pressing the "▲" or "▼" buttons and confirm with the "OK" button. Next, the minutes will start flashing. Set the correct minutes by pressing the "▲" or "▼" buttons and confirm with the "OK" button. The on-time is now set. The clock will then display OFF. Repeat the steps above to set the off-time. The times are now programmed.

### 4. Test Mode

Hold the "▲" button for 5 seconds until the clock lights up white and displays "test." This mode allows you to immediately verify if the light sensor is functioning correctly. There is no delay in this mode.

### 5. Sleep Mode

After 2 minutes of inactivity, the display will turn off to save energy. Touch the "OK" button to reactivate the display.

### 6. Circuit Breaker

The transformer switches off automatically in case of short circuit or overload. The white button at the bottom comes down. Press it to reset the transformer.